

AL ELECTRIC

Anschlussplan Regler | Gleichrichter AL-Electric 58000430





NOTE:

✱ TERMINAL IS **NOT** AN INDICATOR LIGHT. IT IS A TERMINAL THAT BECOMES **POSITIVE** (+) WHEN ALTERNATOR IS CHARGING.

★ TERMINAL BECOMES NEG**ATIVE** (-) WHEN ALTERNATOR IS CHARGING.